

Cessna Skyhawk 172P

Instrument Panel


1. Airspeed Indicator
2. Attitude Indicator (AI)
3. Altimeter
4. VOR/LOC Indicator
5. Turn Coordinator and Inclinometer
6. Heading Indicator (HI)
7. Vertical Speed Indicator (VSI)
8. Automatic Direction Finder (ADF) (ALT+N toggles 2nd VOR/LOC in place of the ADF)
9. Fuel Tank Selector Switch
10. Ignition Switch
11. Battery/Alternator Switch
12. Avionics Power Switch
13. Pitot Heat Switch
14. External Light Switches; Strobe, Beacon, Navigation, Taxi, and Landing
15. Carburetor Heat Lever
16. Throttle Lever
17. Fuel Mixture Lever
18. Pitch Trim Wheel
19. Flaps Lever

20. Oil Temperature Gauge
21. Oil Pressure Gauge
22. Tachometer (RPM)

23. Fuel Gauges
24. Clock

25. Radio Stack (see Radio Stack/GPS diagram)

26. Magnetic Compass



Beechcraft Bonanza V35

Instrument Panel


1. Airspeed Indicator
2. Attitude Indicator (AI)
3. Altimeter
4. Automatic Direction Finder (ADF)
5. Turn Coordinator and Inclinometer
6. Horizontal Situation Indicator (HSI)
7. Vertical Speed Indicator (VSI)
8. VOR/LOC Indicator
9. Fuel Tank Selector Switch
10. Ignition Switch
11. Battery/Alternator Switch
12. Avionics Power Switch
13. Pitot Heat Switch
14. External Light Switches; Strobe, Beacon, Navigation, Taxi, and Landing
15. Cowl Flaps
16. Throttle Lever
17. Propeller Lever
18. Fuel Mixture Lever
19. Pitch Trim Wheel
20. Landing Gear Lever

21. Flaps Lever
22. Fuel Gauges
23. Exhaust Gas Temperature (EGT) Gauge

24. Battery Amperage Level Gauge
25. Oil Temperature Gauge
26. Oil Pressure Gauge

27. Clock
28. Radio Stack (see Radio Stack/GPS diagram)
29. Manifold Pressure/Fuel Flow Gauge

30. Tachometer (RPM)
31. Magnetic Compass



Beechcraft Baron B58

Instrument Panel


1. Airspeed Indicator
2. Attitude Indicator (AI)
3. Altimeter
4. Automatic Direction Finder (ADF)
5. Turn Coordinator and Inclinometer
6. Horizontal Situation Indicator (HSI)
7. Vertical Speed Indicator (VSI)
8. VOR/LOC Indicator
9. Clock
10. Left Engine Manifold Pressure/Fuel Flow Gauge
11. Right Engine Manifold Pressure/Fuel Flow Gauge
12. Left Engine Tachometer (RPM)
13. Right Engine Tachometer (RPM)
14. Synchroscope
15. Magnetic Compass
16. Battery/Alternator Switch
17. Avionics Power Switch
18. Pitot Heat Switch
19. External Light Switches; Strobe, Beacon, Navigation, Taxi, and Landing
20. Propeller Synchronization Switch

21. Throttle Levers
22. Propeller Levers
23. Fuel Mixture Levers
24. Pitch and Rudder Trim Wheels
25. Landing Gear Lever
26. Flaps Lever

27. Radio Stack (swaps with instruments shown – use the Tab key – see Radio Stack/GPS diagram)
28. Left Fuel Tank/Crossfeed Switch
29. Right Fuel Tank/Crossfeed Switch

30. Left Engine Ignition Switch
31. Right Engine Ignition Switch
32. Fuel Boost Switches
33. Cowl Flaps Switch
34. Fuel Gauges
35. Exhaust Gas Temperature (EGT) Gauges

36. Battery Amperage Level Gauges
37. Oil Temperature Gauges
38. Oil Pressure Gauges



Beechcraft Super King Air B200

- 1. Airspeed Indicator
- 2. Electronic Attitude Direction Indicator (EADI)
- 3. Altimeter
- 4. Torque Indicators
- 5. Internal Turbine Temperature (ITT)/Fuel Flow Gauges
- 6. N1 Engine RPMs and Propeller Tachometer (RPM) Gauges
- 7. Oil Temperature/Oil Pressure Gauges
- 8. Radio Magnetic Indicator (RMI)
- 9. Inclinometer
- 10. Electronic Horizontal Situation Indicator (EHSI)
- 11. Vertical Speed Indicator (VSI)
- 12. EHSI Course Index Selector
- 13. EHSI Heading Bug Selector
- 14. Fuel Gauges
- 15. Battery Amperage Level Gauges
- 16. Radio Stack
- 17. Battery/Alternator Switch


- 18. Avionics Power Switch
- 19. Pitot Heat Switch
- 20. Clock
- 21. Fuel Tank/Crossfeed Switches
- 22. Engine Start Switches

- 23. External Light Switches; Strobe, Beacon, Navigation, Taxi, and Landing
- 24. Propeller Synchronization Switch
- 25. Standby Pump Switches

- 26. Power Levers
- 27. Propeller Levers
- 28. Condition Levers
- 29. Pitch, Rudder, and Aileron Trim Wheels
- 30. Landing Gear Lever

Instrument Panel

- 31. Flaps Lever
- 32. Magnetic Compass
- 33. Synchroscope



Cessna CitationJet 525

- 1. Airspeed Indicator
- 2. Electronic Attitude Direction Indicator (EADI)
- 3. Altimeter
- 4. Fan Tachometer (RPM N1) Indicators
- 5. Internal Turbine Temperature (ITT) Indicators
- 6. Turbine Tachometer (RPM N2) Indicators
- 7. Fuel Flow Indicators
- 8. Oil Pressure Indicators
- 9. Oil Temperature Indicators
- 10. Fuel Level Indicators
- 11. Radio Magnetic Indicator (RMI)
- 12. Electronic Horizontal Situation Indicator (EHSI)
- 13. Inclinometer
- 14. Vertical Speed Indicator (VSI)
- 15. EHSI Course Index Selector
- 16. EHSI Heading Bug Selector
- 17. Radio Stack
- 18. Battery Amperage Level Gauges
- 19. Communication Radio (COMM1 and COMM 2) Switches


- 20. Navigation Radio (NAV1 and NAV2) Switches
- 21. Distance Measuring Equipment Switch
- 22. Marker Switch
- 23. Automatic Direction Finder Switch
- 24. Battery/Alternator Switch

- 25. Avionics Power Switch
- 26. Pitot Heat Switch
- 27. Fuel/Crossfeed Switches
- 28. Engine Start Switches
- 29. External Light Switches; Strobe, Beacon, Navigation, Taxi, and Landing
- 30. Speed Brake Switch

- 31. Fuel Boost Switches
- 32. Marker Lights
- 33. Clock
- 34. Thrust Levers
- 35. Pitch, Rudder, and Aileron Trim Wheels
- 36. Landing Gear Lever
- 37. Flaps Lever

Instrument Panel

- 38. Angle of Attack Indicator
- 39. Air Temperature
- 40. Magnetic Compass
- 41. NAV1 Radio Identify Button
- 42. NAV2 Radio Identify Button
- 43. ADF Identify Button



Cessna Skyhawk 172R

- 1. Airspeed Indicator
- 2. Attitude Indicator (AI)
- 3. Altimeter
- 4. VOR/LOC Indicator
- 5. Turn Coordinator and Inclinometer
- 6. Heading Indicator (HI)
- 7. Vertical Speed Indicator (VSI)
- 8. Automatic Direction Finder (ADF) (ALT+N toggles 2nd VOR/LOC in place of the ADF)
- 9. Fuel Tank Selector Switch
- 10. Ignition Switch
- 11. Battery/Alternator Switch
- 12. Avionics Power Switch
- 13. Pitot Heat Switch
- 14. External Light Switches; Strobe, Beacon, Navigation, Taxi, and Landing
- 15. Carburetor Heat Lever
- 16. Throttle Lever
- 17. Fuel Mixture Lever
- 18. Pitch Trim Wheel
- 19. Flaps Lever
- 20. Tachometer (RPM)
- 21. GPS/NAV Switches
- 22. Clock

- 23. Thermometer
- 24. Fuel Gauges
- 25. Exhaust Gas Temperature (EGT) Gauges

- 26. Fuel Flow Gauge
- 27. Oil Temperature Gauge
- 28. Oil Pressure Gauge

- 29. Radio Stack (see Radio Stack/GPS diagram)

Instrument Panel

- 30. Magnetic Compass

